



JX-PA Series Installation Guide



*Mounting screws must accommodate this distance.



*Mounting screws must accommodate this distance.

Mounting

1. To maximize wire rope life, align transducer with moving element so that wire rope exits perpendicular to axis of wire rope exit hole within 2° (see Figure 3).
2. Use Table A or B to determine wire rope exit location relative to transducer mounting holes.
3. Mount unit with two #8 or two M4 (or smaller) pan head machine screws. On units with ranges of 60" (1500 mm) or 80" (2000 mm), place spacer blocks under mounting pods as shown in Figure 2. Torque 8-32 screws to **8 lb-in** maximum. Torque M4 screws to **0.80 N-m** maximum.

Rotation of Wire Rope Exit

To rotate wire rope exit location, loosen four screws (item 1, Figures 1 & 2) which retain mechanism to mounting housing. Note that alignment marks on mechanism occur at 45° intervals. Rotate housing to desired position and torque screws to **50 oz-in (0.35 N-m)**.




Figure 3

Replacement Wire Rope Wipers

The JX transducer contains wire rope dust wipers which are located just beneath the wire rope exit location. Periodic replacement of the dust wipers may be necessary depending upon the amount of dust in the operating environment.

To access the dust wipers, remove the dust wiper cover by placing a small blade screwdriver into the slot as shown in Figure 4 and pry upward while squeezing the ends of the cover. The wipers may be removed with tweezers and cleaned or replaced. The replacement wiper kit which contains six pair of prelubricated wipers is part number 10198.

To install replacement wipers, place a wiper into wiper opening on both sides of the wire rope. Press wiper cover into place until detented.






Figure 4

Circuit Diagram




Connector Wiring

As viewed on transducer and on cable attachment side of mating connector.



Electrical Cable Wiring



Specifications

Input Impedance 1000 ohms $\pm 10\%$
 Excitation Voltage 25 VDC or VAC max.
 Output Impedance 0 to 1000 ohms
 Linearity:
 Ranges to 4.7" $\pm 1.0\%$ Full Scale
 10" to 25" range $\pm 0.5\%$ Full Scale
 30" to 80" range $\pm 0.25\%$ Full Scale
 Operating Temperature -15°C to 60°C

We are here for you. Addresses and Contacts.

Headquarter Switzerland:

Angst+Pfister Sensors and Power AG
Thurgauerstrasse 66
CH-8050 Zurich
Phone +41 44 877 35 00
sensorsandpower@angst-pfister.com

Office Germany:

Angst+Pfister Sensors and Power Deutschland GmbH
Edisonstraße 16
D-85716 Unterschleißheim
Phone +49 89 374 288 87 00
sensorsandpower.de@angst-pfister.com

Office North America:

Angst+Pfister North America Inc.
10391 Brecksville Rd.
US-Brecksville, OH 44141
Phone +1 440 375-5212
info.apus@angst-pfister.com

Scan here and get an overview of personal contacts!



<https://sensorsandpower.angst-pfister.com/en/>
