

'ANALOG' Output Precision Contactless Rotary Position Sensors

Bush Mounting - Sleeve bearing

12 mm Ø metal housing. Mini size

Shaft Ø 3mm, 1/8", optional 6mm


Hall CMOS technology, low cost

Output : 0-5V ratiometric, Measurement range 0° - 360 °

Bush mounting - Sleeve bearing

1-Supply (Red); 2-Output (Grey); 3-Ground (Grey) : **For OCF**

1-Supply; 2-Output; 3-Ground: **For OCT**



ELECTRICAL CHARACTERISTICS

Electrical angle	0 to 360°, any angle from 0-20 to 0-360 programmable in steps of 1°	
Electrical speed (max)	160 rpm	
Resolution	4096 steps (12 bit)	
Signal type	Supply voltage	Output signal
S0505	5V ±10%	0 - 5V ratiometric
Independent linearity tolerance	± 0.5%	
Supply current (mA)	< 16 mA	
Update rate	1 ms	

MECHANICAL CHARACTERISTICS

Mechanical angle	0 - 360°(continuous)
Shaft diameter and length (FMS)	Metric 3 mm Ø X 20mm (MNCB) Inch 1/8" Ø X 20mm (ZNCB)
Bushing	Metric M6 X 0.75 (MNCB) Inch 1/4" X 32 UNEF (ZNCB)
Mechanical speed (Max.)	800 rpm
Rotational life	~ 10 million rotations
Operating torque (approx.)	0.4 to 0.5 Ncm
Operating temperature range	- 40 to +85° C
Weight	10 gm
Interconnection	3 core flat cable 0.15 mtr long

MATERIAL


Housing	Aluminium anodized
Shaft	Stainless Steel
Bearing	Sleeve bearing- teflon



FUNCTION PRINCIPLE

The determination of angular position and signal generation is realised by an intelligent CMOS Hall sensor. A diametrical polarised magnet induces its magnetic field into the sensor. It rotates and provides a conditioned signal to the integrated electronic.

ANALOG OUTPUT



At the output of the sensor a variable voltage or variable current is provided proportional to the position of the shaft / axis over a complete angle range of 360 ° or a subrange. The contactless sensor electronic guarantees a steady signal level and a very low linearity error of 0.5%. With supply voltages of 5VDC $\pm$ 10% output signal of 0 - 5V ratiometric at the sensor output is provided. Besides this a large variety of electrical options such as Output signal level programming, Zero point programming and Centre point programming are provided.

Default Version :

12 mm housing, bush mount, 360° CW Electrical & Mechanical angle, Electrical speed 160 rpm, 3 core flat cable 0.15 mtr long

ORDERING INFORMATION

Refer to electrical and mechanical options on page 1																	
	Housing diameter	Analog output	Metric Miniline (Bush Thread M6X0.75 & Shaft 3 mm Ø)	Inch Miniline (Bush Thread 1/4"x32 UNEF & Shaft 1/8"Ø)	Miniline	Bush mounting	Signal	0 - 5V (ratiometric)	Electrical angle	Direction of rotation	Programming options for non-effective electrical angle (only if elec angle is < 360°)	Delta 1/2 - (default) Low level High level Variable level	Programming options	Output signal level Zero point Center point	Special cable length only for OCF (default 0.15 m long)	Output connection	3 core flat cable 0.15 mtr long - (default) 3 terminals
12	A	M	Z	MP	B	S0505	xxx			CW CCW	PEx PE1 PE2 PE3 PE4	POx POL POZ POC	CVxx	OCx			
12	A	M / Z	MP	B	S0505	xxx	CW / CCW	PEx	POx	CVxx	OCx						

Example with description - **12A MMPB S0505 360CW OCF** - 12 mm diameter, analog output, Miniline, RotaCol bush mount, Metric shaft (Bush Thread M6X0.75 & Shaft 3 mm Ø). Signal - 0-5V ratiometric. 360° angle clockwise. 3 core fl at cable 0.15 mtr long

October 2019 • Subject to change without notice / E & OE, RoHS compliant product

ELECTRICAL OPTIONS FOR ANALOG VERSION 12A M/Z MCB

Electrical options for Effective electrical angle :

Electrical angle (xxx) : Standard configuration is 360°. As an option, any angle from 0-20° to 0-359° in steps of 1° can be programmed.(Price adder)

Output Signal level Programming (POL) : Standard configuration is 0-100%. Output signal can be programmed at any defined lower limit or upper limit in terms of percentage of output. Example : 10% to 90% for S0505 will give output from 0.5V to 4.5V (Price Adder).

Direction of Rotation (CW/CCW) :

CW(Clockwise) When shaft is viewed from top, and rotated in clockwise direction, output increases from minimum to maximum value(standard configuration).




CCW(Counter clockwise) when shaft is viewed from top, and rotated in counter clockwise direction, output increases from minimum to maximum value(Price adder).

Zero point Programming (POZ) :

Standard configuration is zero point without orientation. At POZ, when we do zero point programming rising ramp will start from marking on encoder housing or from the endstop CCW. Zero point can also be programmed at any defined offset from marking on the housing (Price Adder).

Center Point Programming (POC) :

Effective electrical angle is aligned with the mechanical zero point in such a way that equal effective angles in both rotating directions are achieved. Center point can also be programmed at any offset (Price Adder).



Electrical options for Non - Effective electrical angle (Price Adder) : (If electrical angle is < 360°)

Delta 1/2 (PE1) :

If the electrical effective angle is programmed smaller than 360°, the remaining non-effective electrical angle is divided in two equal parts : high level & low level - Delta 1/2.

Low level (PE2) :





If the electrical effective angle is programmed smaller than 360°, after reaching the maximum, the signal level falls to low level.

High level (PE3) :

If the electrical angle is programmed smaller than 360°, the signal level remains high after reaching the full level.

Variable level (PE4) :

If the electrical angle is programmed smaller than 360°, remaining non-effective electrical angle can be divided into high and low level in any ratio according to customer request.



MECHANICAL OPTIONS FOR ANALOG VERSION 12A M/Z MPB

Type / Series	Customized mechanical options
12A M/Z MPB	Special cable length

INTERCONNECTIONS

Standard Interconnections - 3 core flat cable 0.15 mtr long

We are here for you. Addresses and Contacts.

Headquarter Switzerland:

Angst+Pfister Sensors and Power AG
Thurgauerstrasse 66
CH-8050 Zurich
Phone +41 44 877 35 00
sensorsandpower@angst-pfister.com

Office Germany:

Angst+Pfister Sensors and Power Deutschland GmbH
Edisonstraße 16
D-85716 Unterschleißheim
Phone +49 89 374 288 87 00
sensorsandpower.de@angst-pfister.com

Office North America:

Angst+Pfister North America Inc.
10391 Brecksville Rd.
US-Brecksville, OH 44141
Phone +1 440 375-5212
info.apus@angst-pfister.com

Scan here and get an overview of personal contacts!



<https://sensorsandpower.angst-pfister.com/en/>
